



corrugated roof and / or fence

Shopping List

- | | |
|---|---|
| <input type="checkbox"/> Small Bristle or Filament Paintbrush | <input type="checkbox"/> Little Gem Coveralls |
| <input type="checkbox"/> Corrugated Roller Kit | <input type="checkbox"/> Little Gem Sugar Soap |
| <input type="checkbox"/> Gap Filler | <input type="checkbox"/> Painters Tape |
| <input type="checkbox"/> Little Gem Plastic Filling Blades | <input type="checkbox"/> Rokset Wooden or Plastic Paint Stirrer |
| <input type="checkbox"/> General Purpose Sponge | <input type="checkbox"/> Little Gem Cleaning Cloths |
| <input type="checkbox"/> Flexisand Sanding Sponge | <input type="checkbox"/> Rokset Canvas or Plastic Drop Sheet |
| <input type="checkbox"/> Little Gem Dust Masks | <input type="checkbox"/> Tack Cloth or Pocket Duster |
| <input type="checkbox"/> Little Gem Disposable Gloves | <input type="checkbox"/> See the Painters Checklist for a comprehensive list of products that you may require to complete your project. |

Always consult your local paint specialist for professional advice on the correct paint to use. Closely follow the instructions on the paint can.

Preparation

- Fill any holes or cracks with the appropriate filler and allow to cure as per instructions.
- Sand surfaces smooth to remove old paint and sharp edges and to smooth fillers. Use a wire brush followed by a light sanding with a sanding block. (NB: sanding dust from all surface types can be harmful. Use dust masks, gloves and coveralls to protect yourself and your clothing).
- Thoroughly wash and degrease surfaces using sugar soap. Allow to dry completely before painting. If necessary, use a moss and mould cleaner prior to painting.
- Tape up adjoining surfaces and around any fixtures or fittings.
- Rinse rollers and brushes in solvent or water, dependent on the paint type. Allow to dry before use.
- Immediately before painting use a tack cloth or pocket duster to remove excess dust and fine particles.

Application

- Paint drying times vary depending on temperature. Consult your paint professional for advice on ideal painting conditions.
- Speak to your paint specialist about applying a base coat, primer or rust resistant application. Priming is especially important on surfaces that have never been painted.
- Using a brush paint a 50–100mm border around the fence or roof surface and any fittings. This is known as cutting in. When completing your project do not paint over the area that has been cut in by the brush.
- Using a corrugated roller apply paint in a straight line following the corrugations of the surface in one direction and then the other. Place the roller on the next set of corrugations and repeat until complete. Be careful not to overlap on corrugations as this may affect the paint finish.
- Repeat this process for each coat. The number of coats required will depend on the paint, surface and application method used. Follow instructions on the paint can regarding drying times.

Clean up and Care

See Brush and Roller Care and Cleaning for full cleaning and product care instructions.

This fact sheet is intended as a guide only. Rokset does not warrant the accuracy of this information. For professional advice on your particular task, please speak to your local paint specialist.