



painting cupboards and drawers

Shopping List

- | | |
|---|---|
| <input type="checkbox"/> Little Gem Opal Wall Brush | <input type="checkbox"/> Little Gem Dust Masks |
| <input type="checkbox"/> Little Gem Opal Cutter Brush | <input type="checkbox"/> Little Gem Disposable Gloves |
| <input type="checkbox"/> Little Gem Mini Foam Roller Complete | <input type="checkbox"/> Little Gem Coveralls |
| <input type="checkbox"/> or Little Gem Mini Foam Kit | <input type="checkbox"/> Little Gem Sugar Soap |
| <input type="checkbox"/> Spare Foam Sleeves | <input type="checkbox"/> Painters Tape |
| <input type="checkbox"/> Mini Roller Tray | <input type="checkbox"/> Rokset Wooden or Plastic Paint Stirrer |
| <input type="checkbox"/> Gap Filler | <input type="checkbox"/> Little Gem Cleaning Cloths |
| <input type="checkbox"/> Little Gem Plastic Filling Blades | <input type="checkbox"/> Rokset Canvas or Plastic Drop Sheet |
| <input type="checkbox"/> General Purpose Sponge | <input type="checkbox"/> Tack Cloth or Pocket Duster |
| <input type="checkbox"/> Flexisand Sanding Sponge | <input type="checkbox"/> See the Painters Checklist for a comprehensive list of products that you may require to complete your project. |

*Always consult your local paint specialist for professional advice on the correct paint to use.
Closely follow the instructions on the paint can.*

Preparation

- Remove drawer fronts and cupboard doors. Remove all hardware from the doors and drawers.
- Fill any holes or cracks with the appropriate filler and allow to cure as per instructions.
- Sand surfaces smooth to remove old paint and sharp edges and to smooth fillers. Always sand along the grain of the timber. (NB: sanding dust from all surface types can be harmful. Use dust masks, gloves and coveralls to protect yourself and your clothing).
- Thoroughly wash and degrease surfaces using sugar soap. Allow to dry completely before painting.
- Rinse rollers and brushes in solvent or water, dependent on the paint type. Allow to dry before use.
- Immediately before painting use a tack cloth or pocket duster to remove excess dust and fine particles.

Application

- Speak to your paint specialist about applying a base coat, primer or rust resistant application. Priming is especially important on surfaces that have never been painted.
- For the best brush finish apply paint, varnish or stain from side to side in smooth strokes. Start at the top and work your way down. This allows drips to be painted over. Concentrate on one area at a time. Finish strokes off by gently going over with a mini roller. This will remove any ridges that may form. Paint applied too liberally will run.
- Repeat this process for each coat. The number of coats required will depend on the paint, surface and application method used. Follow instructions on the paint can regarding drying times.
- If desired varnish can be applied as a final coat for a clear finish.

Clean up and Care

See Brush and Roller Care and Cleaning for full cleaning and product care instructions.

*This fact sheet is intended as a guide only. Rokset does not warrant the accuracy of this information.
For professional advice on your particular task, please speak to your local paint specialist.*