



interior walls and ceiling

Shopping List

- | | |
|--|---|
| <input type="checkbox"/> Little Gem All Paints Roller Kit | <input type="checkbox"/> Little Gem GP Sponge |
| OR | <input type="checkbox"/> Flexisand Sanding Sponge |
| <input type="checkbox"/> Little Gem Roller Tray | <input type="checkbox"/> Little Gem Dust Masks |
| <input type="checkbox"/> Little Gem H/D Cage Frame | <input type="checkbox"/> Little Gem Disposable Gloves |
| <input type="checkbox"/> Little Gem Wall/Ceiling Cover
10mm nap | <input type="checkbox"/> Little Gem Coveralls |
| | <input type="checkbox"/> Little Gem Sugar Soap |
| | <input type="checkbox"/> Painters Tape |
| <input type="checkbox"/> Little Gem Extension Pole | <input type="checkbox"/> Rokset Wooden or Plastic Paint Stirrer |
| <input type="checkbox"/> Little Gem Opal Wall Brushes | <input type="checkbox"/> Little Gem Cleaning Cloths |
| <input type="checkbox"/> Little Gem Opal Cutter Brushes | <input type="checkbox"/> Rokset Canvas or Plastic Drop Sheet |
| <input type="checkbox"/> Gap Filler | <input type="checkbox"/> Rokset Tack Cloth or Pocket Duster |
| <input type="checkbox"/> Little Gem Plastic Filling Blades | <input type="checkbox"/> See the Painters Checklist for a comprehensive list of products that you may require to complete your project. |

Preparation

- Fill any holes or cracks with the appropriate filler and allow to cure as per instructions.
- Sand surfaces smooth to remove old paint and sharp edges and to smooth fillers. (NB: sanding dust from all surface types can be harmful. Use dust masks, gloves and coveralls to protect yourself and your clothing).
- Thoroughly wash and degrease surfaces using sugar soap. Allow to dry completely before painting. High use areas such as kitchens may require this step to be repeated.
- Tape up adjoining surfaces and around fixtures and fittings.
- Rinse rollers and brushes in solvent or water, dependent on the paint type. Allow to dry before use.
- Immediately before painting use a tack cloth or pocket duster to remove excess dust and fine particles.

Application

- Always take the necessary safety precautions when painting. Remember ladder safety and keep the floor clear to avoid accidents.
- Speak to your paint specialist about applying a base coat, primer or rust resistant application. Priming is especially important on surfaces that have never been painted.
- Using a brush paint a 50–100mm border around the wall area, this is known as cutting in. Cut in around power points and light switches using a smaller border of about 25-50mm. When completing your project do not paint over the area that has been cut in by the brush.
- To start push roller and/or extension pole in a diagonal motion along the wall to form an 'M' about a metre wide. Going in the opposite direction form a 'W' to fill the gaps. Keep contact with the surface during this process and apply even pressure for a smooth finish.
- Next roll in a criss-cross motion to ensure complete coverage.
- Finish this section rolling lightly in vertical strokes from floor to ceiling as directed in Painting with Rollers.
- Move to next section and repeat above steps.
- Repeat this process for each coat. The number of coats required will depend on the paint, surface and application method used. Follow instructions on the paint can regarding drying times.

Clean up and Care

See Brush and Roller Care and Cleaning for full cleaning and product care instructions.

This fact sheet is intended as a guide only. Rokset does not warrant the accuracy of this information.

For professional advice on your particular task, please speak to your local paint specialist.

Closely follow the instructions on the paint can.