



exterior flooring painting

Shopping List

- | | |
|--|---|
| <input type="checkbox"/> All Rounder Black Foam Cover | <input type="checkbox"/> Little Gem Disposable Gloves |
| <input type="checkbox"/> Little Gem H/D Cage Frame | <input type="checkbox"/> Little Gem Coveralls |
| <input type="checkbox"/> Little Gem Extension Pole | <input type="checkbox"/> Little Gem Sugar Soap |
| <input type="checkbox"/> Little Gem Roller Tray | <input type="checkbox"/> Little Gem Cover Quick |
| <input type="checkbox"/> Little Gem Opal Wall Brushes | <input type="checkbox"/> Rokset Wooden or Plastic Paint Stirrer |
| <input type="checkbox"/> Gap Filler | <input type="checkbox"/> Little Gem Cleaning Cloths |
| <input type="checkbox"/> Little Gem Plastic Filling Blades | <input type="checkbox"/> Rokset Canvas or Plastic Drop Sheet |
| <input type="checkbox"/> Little Gem GP Sponge | <input type="checkbox"/> Rokset Tack Cloth or Pocket Duster |
| <input type="checkbox"/> Flexisand Sanding Sponge | <input type="checkbox"/> See the Painters Checklist for a comprehensive list of products that you may require to complete your project. |
| <input type="checkbox"/> Little Gem Dust Masks | |

Preparation

Speak to your concrete/cement professional for the best advice on new concrete, curing treatments, excess moisture tests and different cement preparations. This preparation guide is for existing concrete floors.

- Fill any holes or cracks with the appropriate filler and allow to cure as per instructions.
- Thoroughly wash and degrease surfaces using sugar soap. This is best done using a stiff bristle broom. Rinse with clean water and repeat process if grease and dirt remain. Allow to dry completely before painting. If necessary, use a moss and mould cleaner prior to painting.
- Water blasting will provide an excellent surface for painting. Water blast at 3000 psi and allow surface to dry for at least 24 hours before starting paint application.
- Tape up adjoining surfaces and around any fixtures or fittings.
- Rinse rollers and brushes in solvent or water, dependent on the paint type. Allow to dry before use.

Application

- Paint drying times vary depending on temperature. Consult your paint professional for advice on ideal painting conditions.
- Speak to your paint specialist about applying a base coat, primer or concrete sealant. Priming is especially important on surfaces that have never been painted.
- The easiest and best way to apply paint to your concrete flooring is with a roller and roller pole. Brushes should be used for corners and edging.
- Using a brush paint a 50–100mm border around the floor surface. This is known as cutting in. When completing your project do not paint over the area that has been cut in by the brush.
- To start push roller along the floor as directed in Painting with Rollers.
- Repeat this process for each coat. The number of coats required will depend on the paint, surface and application method used. Follow instructions on the paint can regarding drying times.
- Check with your paint specialist if a final sealant coat is required.

Clean up and Care

See Brush and Roller Care and Cleaning for full cleaning and product care instructions.

*This fact sheet is intended as a guide only. Rokset does not warrant the accuracy of this information.
For professional advice on your particular task, please speak to your local paint specialist.
Closely follow the instructions on the paint can.*