



timber decking and fencing

Shopping List

- | | |
|--|---|
| <input type="checkbox"/> All Rounder All Finish Kit | <input type="checkbox"/> Flexisand Sanding Sponge |
| OR | <input type="checkbox"/> Little Gem Dust Masks |
| <input type="checkbox"/> Little Gem Roller Tray | <input type="checkbox"/> Little Gem Disposable Gloves |
| <input type="checkbox"/> Little Gem H/D Cage Frame | <input type="checkbox"/> Little Gem Coveralls |
| <input type="checkbox"/> Pro Decking Roller | <input type="checkbox"/> Little Gem Sugar Soap |
| <input type="checkbox"/> Little Gem Extension Pole | <input type="checkbox"/> Little Gem Cover Quick |
| <input type="checkbox"/> Little Gem Opal Wall Brushes | <input type="checkbox"/> Rokset Wooden or Plastic Paint Stirrer |
| <input type="checkbox"/> Rokset Polishing and Staining Pad | <input type="checkbox"/> Little Gem Cleaning Cloths |
| <input type="checkbox"/> Gap Filler | <input type="checkbox"/> Rokset Canvas or Plastic Drop Sheet |
| <input type="checkbox"/> Little Gem Plastic Filling Blades | <input type="checkbox"/> Rokset Tack Cloth or Pocket Duster |
| <input type="checkbox"/> Little Gem GP Sponge | <input type="checkbox"/> See the Painters Checklist for a comprehensive list of products that you may require to complete your project. |

Preparation

- Loose timber boards should be fastened firm. Ensure all nails sit just below the surface.
- Fill any holes or cracks with the appropriate filler and allow to cure as per instructions.
- Sand surfaces smooth to remove old paint and sharp edges and to smooth fillers. Always sand along the grain of the timber. (NB: sanding dust from all surface types can be harmful. Use dust masks, gloves and coveralls to protect yourself and your clothing).
- Thoroughly wash and degrease surfaces using sugar soap. Allow to dry completely before painting. If necessary, use a moss and mould cleaner prior to painting.
- Tape up adjoining surfaces and around any fixtures or fittings.
- Lay drop sheets to protect surrounding areas.
- Rinse rollers and brushes in solvent or water, dependant on the paint type. Allow to dry before use.
- Immediately before painting use a tack cloth or pocket duster to remove excess dust and fine particles.

Application - continued on next page

*This fact sheet is intended as a guide only. Rokset does not warrant the accuracy of this information.
For professional advice on your particular task, please speak to your local paint specialist.
Closely follow the instructions on the paint can.*



timber decking and fencing

Application

- Paint drying times vary depending on temperature. Consult your paint professional for advice on ideal painting conditions.
- Always take the necessary safety precautions when painting. Remember ladder safety and keep the floor clear to avoid accidents.
- Stain and paint should not be applied to timber that has a high moisture content. Contact your local paint specialist for further information.
- Speak to your paint specialist about applying a base coat, primer, timber pre-treatment or rust resistant application. Priming is especially important on surfaces that have never been painted.
- Apply stain or paint to timber using a brush or roller along the length of the grain or grooves of the timber. Wipe off excess timber stain with a clean, lint free cloth and finish coating the area as directed in Painting with Brushes or Rollers.
- Always apply stain or paint to the end grains (i.e. underneath the fence). This will prevent moisture penetration which can eventually lead to timber cracking and rotting.
- Repeat this process for each coat. The number of coats required will depend on the paint, surface and application method used. Follow instructions on the paint can regarding drying times.

Clean up and Care

See Brush and Roller Care and Cleaning for full cleaning and product care instructions.

*This fact sheet is intended as a guide only. Rokset does not warrant the accuracy of this information.
For professional advice on your particular task, please speak to your local paint specialist.
Closely follow the instructions on the paint can.*